


From: Debbie Feuerstein <debbie@intellitecusa.com>
Sent: Wednesday, March 25, 2015 1:56 PM
To: Jeffrey Mishan <Jeffrey.Mishan@emsonusa.com>
Cc: Mindy Farber <Mindy.Farber@emsonusa.com>; Feena SanPedro <Feena.SanPedro@emsonusa.com>
Subject: BELL&HOWELL ULTRASONIC PEST REPELLER TEST REPORT REVISED
Attach: 1_Cover Page.pdf; BELL&HOWELL ULTRASONIC PEST REPELLER TEST REPORT.PDF

Dear Jeffrey;

Attached #1 is revised report cover page.

Attached #2 is revised report in pdf format.



Warm regards,
Debbie Feuerstein
INTELLITEC INT'L INC.
T: 718-8840038 | C: 646-2208585
Intelligence thru Technology

BELL + HOWELL ULTRASONIC PEST REPELLER

EFFICACY TEST REPORT

- SGS EFFICACY TEST REPORT – MICE/RAT
- SGS TEST RESULT EXPLANATION – MICE/RAT
- SGS EFFICACY TEST REPORT – SPIDERS/ANTS/ROACHES
- SGS TEST RESULT EXPLANATION – SPIDERS/ANTS/ROACHES
- INTERTEK EFFICIACY TEST REPORT – MICE/RAT
- INTERTEK RESULT EXPLANATION – MICE/RAT
- INTERTEK EFFICACY TEST REPORT - SPIDERS/ANTS/ROACHES
- INTERTEK RESULT EXPLANATION - SPIDERS/ANTS/ROACHES



BELL + HOWELL ULTRASONIC PEST REPELLER

EFFICACY TEST REPORT

- SGS EFFICACY TEST REPORT – MICE/RAT
- SGS TEST RESULT EXPLANATION – MICE/RAT
- SGS EFFICACY TEST REPORT – SPIDERS/ANTS/ROACHES
- SGS TEST RESULT EXPLANATION – SPIDERS/ANTS/ROACHES
- INTERTEK EFFICIACY TEST REPORT – MICE/RAT
- INTERTEK RESULT EXPLANATION – MICE/RAT
- INTERTEK EFFICACY TEST REPORT - SPIDERS/ANTS/ROACHES
- INTERTEK RESULT EXPLANATION - SPIDERS/ANTS/ROACHES




BELL + HOWELL ULTRASONIC PEST REPELLER

EFFICACY TEST REPORT



WITNESS TEST REPORT

Date: 15-Dec-2011

SGS File No.:	CNDGG50037334	Testing Device
Buyer :	VAN HAUSER 230, FIFTH AVENUE, NEW YORK, NY 10001, USA	
Style Number:	Nil	
Product description:	BELL + HOWELL ULTRASONIC PEST REPELLER	
Service Style :	TESTING WITNESS	
Service Date :	From 01-DEC-201 to 11-DEC-201	
Testing Location :	DONGGUAN, CHINA	

Testing sample provided by	By Supplier(see protocol)
Client instruction/specification	Yes(see protocol)
SGS WI number	N/A
Other	

- Found 1rat escaped and 2 rats died at the night of 02-Dec-2011 (preliminary testing), added the new rats next day (on the first day of during testing).
- Found water spilled into food dish in Chamber A&B on 02-Dec-2011, so Chamber B food weight added 49 g.
- Four edges of all chambers were closed up by SGS inspector with special seals. The seal is unbreakable and chopped with SGS company stamp. Each day after counting mice/rat quantities and weighting water and food, SGS inspector replaced new seals.

Page : of 17

BHH,LLC 002513



STUDY TITLE

EFFICACY EVALUATION OF BELL + HOWELL ULTRASONIC PEST REPELLER AGAINST MICE/RATS

OBJECT

TESTING ULTRASONIC PEST REPELLER AGAINST RATS / MICE IN LABORATORY ENVIRONMENT. CONDUCTING OBSERVATIONS IN TOTAL 11 DAYS PERIOD, INCLUDING 2 DAYS PRELIMINARY TEST, 7 DAYS DURING TEST AND 2 DAYS POST TEST IN RATS / MICE, THIS IS TO MEASURE THE EFFICACY OF HIGH-FREQUENCY SOUND AS A PEST MANAGEMENT TOOL. BOTH FREQUENCY AND SOUND PRESSURE (DB) ARE IMPORTANT PARAMETERS.

MATERIALS

FORMULATIONS	BELL + HOWELL ULTRASONIC PEST REPELLER
TEST ARTHROPODS	ADULT & HEALTHY RATS AND MICE
APPLICATION DEVICES	BELL + HOWELL ULTRASONIC PEST REPELLER
TESTING CHAMBER	SEE BELOW DIAGRAM

METHODS

Summary

7 feet long plastic tunnel is made to connect two chambers on each side. Each chamber is 4 feet (L) x 4 feet (W) x 1.5 feet (H). Ultrasonic Pest Repeller is placed at Chamber A, Chamber B has no ultrasonic pest repeller. Both sides have equal amount of food and water. Rats and Mice will be recorded at 24 hour intervals for 11 days, including 7 days (or 168 hours) - 2 days Preliminary Testing and 2 days Post Testing. The number of rats / mice will be recorded in each chamber. Any rats / mice are found in Chamber B (no ultrasonic pest repeller) will be counted as repelled. Any rats / mice remain in Chamber A (with ultrasonic pest repeller) will be counted as not repelled.

To determine the efficacy of the Bell + Howell Ultrasonic Pest Repeller for repelling rats and mice. This device is tested over a 24 hours interval and 7 days (or 168 hours) period in a laboratory environment. The test was preceded by a two-day preliminary test to ensure that the test apparatus and the selected food functioned properly.

Test sample

The test sample will be stored in a locked cabinet at ambient temperature and humidity until use in the study.




Preparation and Handling of Rats/Mice

10 Mixed Sex Adult Rats and 10 Mixed Sex Adult Mice will be used for both the control test and active test. As rats are larger and far more aggressive than mice, they can, and often do, kill mice. This is known as muricide. Muricide is a form of predatory behavior by which rats hunt, kill and eat mice. Therefore the testing of rats and mice must be conducted separately in different times.



Construction of Test Chambers

The test will be conducted in two plastic chambers; each chamber is 4 feet (L) x 4 feet (W) x 1.5 feet (H). In between, there is a 7 feet long plastic tunnel to connect two chambers on each side, the rats and mice will each be given 7 days (168 hours) to move freely around Chamber A and Chamber B and inside the tunnel.





Food and Water Consumption

Rats eat a wide variety of food. They mostly prefer grain, livestock feed, and meat. The rat's primary consumption comes in the form of water. Rats need 1/2 to 1 ounce of water daily. An equal amount of food and water will be placed in each chamber, including a mixture of grain and meat. Food and water will be refilled and recorded daily.

Mice prefer pellet- and seed-based food. Mice generally eat food common to the rodent family, (rats, hamsters, gerbils, etc.), which typically includes pellet- and seed-based food. An equal amount of food and water will be placed in each chamber. The quantity of food and water will be refilled and recorded daily.

Data related to food and water consumption will be recorded in each chamber on a 24-hour interval throughout a 7-day (or 168 hours) period. The data will be used to identify changes in the eating behavior of mice and rats due to the impact of the Ultrasonic Pest Repeller.

Fecal pellet counts & Urine spots

Record and tract fecal pellets and urine spots on a 24 hours interval and 2 days Preliminary Testing, 7 days (or 168 hours) During Testing and 2 days Post Testing period in each chamber. This data will aid in understanding additional behavioral changes resulting from the Ultrasonic Pest Repeller.

Preliminary Testing

Rats/Mice activity will be documented before and after device installation. To observe general activity, a Preliminary Test will be conducted before the actual test to ensure the test apparatus and the selected food functioned properly. The Ultrasonic Pest Repeller will be turned "off" during preliminary testing. The release of rats and mice in Chamber A and Chamber B will be proportionate, with 50% of rats and mice distributed in each chamber.

The Preliminary Test will consist of 10 mixed sex adult rats and 10 mixed sex adult mice. The rats and mice will be each allotted 2 days (48 hours) to move freely around chamber A, Chamber B and inside the tunnel prior to the introduction of the Ultrasonic Pest Repeller.

Observation of Repellency (During Testing)

Release 50% of rats in Chamber A, and another 50% of mice in Chamber B. Turn On Ultrasonic Pest Repeller. Rats and mice will be recorded at 24 hour intervals for 7 days (or 168 hours). Any rats and mice that stay in the Chamber B (without ultrasonic pest repeller) will be counted as repelled. Any rats and mice stay inside Chamber A (with ultrasonic pest repeller) will be counted as not repelled.

The actual control and non-control test will consist of 10 mixed sex adult rats and 10 mixed sex adult mice. The rats and mice will each be given 7 days (168 hours) to move freely around Chamber A and Chamber B and inside the tunnel.



Post Testing

To observe general activity, a post test will be conducted to ensure the test apparatus and the selected food functioned properly. Ultrasonic Pest Repeller will be turned OFF during post test. Release 50% of rats and mice in Chamber A, release another 50% of rats and mice in Chamber B.


The Post Test consists of 10 mixed sex adult rats and 10 mixed sex adult mice. The rats and mice are each given 2 days (48 hours) to move freely around chamber A, Chamber B and inside the tunnel.

No change is made in the rats / mice population. Rats and mice quantity should remain the same.




Testing device dimension (refer to below following figures)

Testing device for RATS:




Testing device for MICE.




Note: Distance between the two devices was about 20 m


SGS



RATS TESTING DEVICE OVERLOOK



SGS UN-REMOVABLE SEAL LABEL



MICE TESTING DEVICE OVERLOOK



SGS UN-REMOVABLE SEAL LABEL



Test Result Data Measurement – RATS

RATS		DURING TESTING										POST TESTING	
		PRELIMINARY TESTING		SWITCH ON								SWITCH OFF	
		18Hrs (-2 Day)	24Hrs (-1 Day)	2 Hrs (1 Day)	18Hrs (2 Day)	72Hrs (3 Day)	96Hrs (4 Day)	120Hrs (5 Day)	144Hrs (6 Day)	168Hrs (7 Day)	192Hrs (8 Day)	216Hrs (9 Day)	240Hrs (10 Day)
Observe Date		1-Dec-11	2-Dec-11	3-Dec-11	4-Dec-11	5-Dec-11	6-Dec-11	7-Dec-11	8-Dec-11	9-Dec-11	10-Dec-11	11-Dec-11	12-Dec-11
Observe Time		10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM
Chamber A (W/Pest Repeller)	quantity	1	2	0	0	0	0	0	0	0	0	5	7
	consumed food(g)	36	20	1	7	3	7	10	11	6	151	172	
	consumed water(ml)	366	181	62	64	25	26	34	44	41	214	88	
Chamber B	quantity	2	5	16	10	10	10	10	10	10	10	10	3
	consumed food(g)	49	116	142	137	202	166	221	156	203	154	181	
	consumed water(ml)	512	181	387	360	266	245	343	344	301	215	90	

Note:

1. Found 1 rat escaped and 2 rats died at the night of 02-Dec-2011 (preliminary testing), added the new rats next day (on the first day of during testing).
2. Found water spilled into food dish in Chamber A&B on 02-Dec-2011, and Chamber B food weight added 49 g.



Rats testing status

Rats testing status

Page 4 of 17

SGS F-OPS-05 01-CTS V06

This document is issued by the Company, under its General Conditions of Service accessible at www.spa.be/conditions. Attention is drawn to the fact that information and/or data issues referred herein, are the property of the Company and are confidential. Any holder of this document is explicitly limited to verbal communication of the content and readily accessible portions of the document's findings at the time of its intervention only, and without any obligation of confidentiality. The Company's sole responsibility is to its Client, and this document does not constitute a transaction from which any rights and obligations under the transaction documents may be derived. Any violation of the confidentiality of the content or appearance of this document is unlawful and offenders may be prosecuted to the fullest extent of the law.

BHH,LLC 002521

SGS

Test Result Data Measurement – MICE

MICE		PRELIMINARY TESTING		DURING TESTING								POST TESTING	
		SWITCH OFF		SWITCH ON								SWITCH OFF	
		48Hrs (2 Day)	24Hrs (1 Day)	48Hrs (2 Day)	72Hrs (3 Day)	96Hrs (4 Day)	120Hrs (5 Day)	144Hrs (6 Day)	168Hrs (7 Day)	+24Hrs (+1 Day)	+48Hrs (+2 Day)		
Observe Date		1-Dec-11	2-Dec-11	3-Dec-11	4-Dec-11	5-Dec-11	6-Dec-11	7-Dec-11	8-Dec-11	9-Dec-11	10-Dec-11	11-Dec-11	
Observe Time		10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	
Chamber A (W/Pest Repeller)	quantity	5	0	1	2	1	1	1	0	0	0	0	
	consumed food(g)	67	51	14	7	7	7	4	4	22	21	21	
	consumed water(ml)	82	28	21	25	11	10	24	29	35	27	27	
Chamber B	quantity	18	10	9	8	9	9	9	10	10	2	2	
	consumed food(g)	46	17	23	32	35	23	36	44	16	18	18	
	consumed water(ml)	109	35	31	30	17	20	42	44	37	30	30	

Page 16 of 17

SGS-F-OPS-05-01-C1 S V06


This document is issued by the Company under its General Conditions of Service accessible at http://www.sgs.com/terms_and_conditions. Attention is drawn to the limitation of liability, indemnification and jurisdiction clauses defined therein. Any holder of this document is advised that information contained herein is solely for the use of the client and is not to be used for any other purpose. The Company's sole responsibility is to its Client and this document does not exonerate the Client from exercising all the rights and obligations under the transaction documents. Any unauthorized alteration, forgery or falsification of the content or appearance of this document is unlawful and offenders may be prosecuted to the fullest extent of the law.

BHH,LLC 002522

SGS



Mice testing status



Mice testing status




RATS/MICE FECAL PELLET & URINE SPOTS RECORD REPORT

STAGE/ SWITCH ON/OFF		DATE	SUBJECT	CHAMBER : A (W/ PEST PELLER)	CHAMBER : B
PRELIMINARY TESTING	SWITCH OFF	1-Dec-11	MICE	Little	More
			RATS	Equal	Equal
		2-Dec-11	MICE	More	Little
			RATS	Equal	Equal
DURING TESTING	SWITCH ON	3-Dec-11	MICE	Little	More
			RATS	Little	More
		4-Dec-11	MICE	Very little	More
			RATS	Very little	More
		5-Dec-11	MICE	Very little	More
			RATS	Little	More
		6-Dec-11	MICE	Very little	More
			RATS	Very little	More
		7-Dec-11	MICE	Very little	More
			RATS	Very little	More
		8-Dec-11	MICE	Very little	More
			RATS	Very little	More
POST TESTING	SWITCH OFF	10-Dec-11	MICE	Equal	Equal
			RATS	Equal	Equal
		11-Dec-11	MICE	Equal	Equal
			RATS	Equal	Equal


Note:

Fecal pellet and urine spots are observed and witnessed by eyes. Due to tiny and irregular sizes, rat and mice's fecal pellet & urine spots are not easy to count, therefore quantity difference is described by three levels – little, very little and more.


SGS




DEVICE WITH FOOD AND WATER




ONLY ONE PET REPELLER IN THE DEVICE



CHAMBER A



CHAMBER B




SGS SEAL LABEL



SGS SEAL LABEL


SGS




RATS TESTING DEVICE OVERLOOK



RATS TESTING DEVICE OVERLOOK



STATUS UNDER REPELLER SWITCHED OFF



STATUS UNDER REPELLER SWITCHED OFF



STATUS UNDER REPELLER SWITCHED ON




STATUS UNDER REPELLER SWITCHED ON


SGS




MICE TESTING DEVICE OVERLOOK



MICE TESTING DEVICE OVERLOOK




STATUS UNDER REPELLER SWITCHED OFF



STATUS UNDER REPELLER SWITCHED OFF




STATUS UNDER REPELLER SWITCHED ON



STATUS UNDER REPELLER SWITCHED ON

SGS



WATER GROSS WEIGHT CHECK




RENOVATE WATER WEIGHT



FOOD GROSS WEIGHT CHECK



RENOVATE FOOD WEIGHT



SPRINKLE FOOD



FOOD & WATER IN CHAMBER

RATS/MICE TEST REPORT RESULT ANALYSIS

December 19, 2011

Construction of Test Chamber:

- The test was conducted in two plastic chambers. Each chamber is 4' x 4' x 1.5'.
- Pest Repeller was placed in chamber A.
- In between, there is a 7 feet long plastic tunnel. The tunnel is "curved" and two chambers are designed in HI-LO level. The curved and Hi-Lo tunnel design is to further ensure ultrasonic sound wave will not enter from chamber A into chamber B since sound wave is very directional.
- All edges are sealed securely with SGS unbreakable labels. Only SGS inspector could open the chambers to count rats/mice quantities, weight food and water and replace new seals on a daily basis.
- Total 10 mixed rats and 10 mixed mice were used, and tested separately in different chambers.
- Released 50% of rats/mice in chamber A, and another 50% of rats/mice in Chamber B at the beginning of the test.
- There were 3 testing stages;
 - Preliminary Testing: 2 days = 48 hours, pest repeller was OFF
 - During Testing: 7 days = 168 hours, pest repeller was ON
 - Post Testing: 2 days = 48 hours, pest repeller was OFF

Rats – Test Result Analysis (see page 8)

- From the 1st day to 7th day During Testing, 100% rats stayed away from pest repeller chamber through the entire time, pest repeller was on.
- Some rats stayed or returned to the pest repeller chamber during Preliminary and Post Testing, pest repeller was off.
- Water and food consumption was much LESS in the pest repeller chamber During Testing, pest repeller was on. The consumption became more EVEN in two chambers during Preliminary and Post Testing, pest repeller was off. To record water and food consumption result on a daily basis helps to understand rats' eating behavior under the influence of ultrasonic sound.

Mice – Test Result Analysis (see page 10)

- Average 90% ~ 100% mice stayed away from pest repeller chamber During Testing (pest repeller was on).
- Some mice stayed or returned to the pest repeller chamber during Preliminary and Post testing (pest repeller was off).
- Water and food consumption was much LESS in the pest repeller chamber During Testing, pest repeller was on. The consumption became more EVEN in two chambers during Preliminary and Post Testing, pest repeller was off. To record water and food consumption result on a daily basis helps to understand mice's eating behavior under the influence of ultrasonic sound.

Fecal Pellet and Urine Spots (see page 12)

- To trace and record rats and mice's fecal pellet and urine spots on a daily basis is to further understand rats and mice's activities and behaviors under the influence of ultrasonic sound.
- When pest repeller was on During Testing; fecal pellet and urine spots appeared to be much LESS quantities in the pest repeller chamber.
- When pest repeller was off during Preliminary and Post Testing, fecal pellet and urine spots quantities appeared to be more EVEN in two chambers.




SGS-CSTC Shenzhen Branch
7/F, SGS Building No. 4, Jianghao Industry Park, No. 430, Jihua Road,
Bantian Town, Longgang District, Shenzhen, China. P.C. 518129 Tel: 86 755 25328888 / 83114358 Fax: 86 755 83139706 / 83139732

WITNESS TEST REPORT

Report No.: SZXWT00603439

To :	INTELLITEC INTERNATIONAL INC.	Date:	23-MAR-2012
Att :	DEBBIE FEUERSTEIN		
From :	Mei Lv	E-mail :	Mei.Lv@sgs.com

SGS File No.:	CNDGG50041547	Testing Device	Overlook
Buyer :	VAN HAUSER 230, FIFTH AVENUE, NEW YORK, NY 10001, USA		
Supplier :	INTELLITEC INTERNATIONAL INC.		
Manufacturer :	INTELLITEC INTERNATIONAL INC.		
Style Number:	Nil		
Product description:	BELL + HOWELL ULTRASONIC PEST REPELLER		
Service Style :	TESTING WITNESS		
Service Date :	From 10-MAR-2012 to 21-MAR-2012		
Testing Location :	DONGGUAN, CHINA		


Testing Criteria

Testing sample provided by	By Supplier(see protocol)
Client instruction/specification	Yes(see protocol)
SGS WI number	N/A
Other	

Comments / Remarks: (Reason)

- Canceled bread and white granulated sugar (as food) for spiders on 12-Mar-2012, as spiders were not eating & drinking.
- Each spider chambers provided 10 recently dead roaches as food for spiders on a daily basis. Used soaked sponges to feed spiders water.
- Four edges of all chambers were sealed by SGS inspectors with un-removable seal labels and chopped with SGS stamp. Each day after counting spiders/ants/roaches quantities and weighting water, inspector replaced new seals.

Page 1 of 19



This document is issued by the Company under its General Conditions of Service accessible at http://www.sgs.com/terms_and_conditions. The attention is drawn to the limitation of liability, indemnification and jurisdiction issues defined therein. Any holder of this document is advised that information contained hereon is solely limited to visual examination of the safely and readily accessible portions of the consignment and reflects the Company's findings at the time of its intervention only and within the limits of Client's instructions, if any. The Company's sole responsibility is to its Client and this document does not exonerate parties to a transaction from exercising all their rights and obligations under the transaction documents. Any unauthorized alteration, forgery or falsification of the content or appearance of this document is unlawful and offenders may be prosecuted to the fullest extent of the law.

BHH,LLC 002531



STUDY TITLE

EFFICACY EVALUATION OF BELL + HOWELL ULTRASONIC PEST REPELLER
AGAINST
ANTS / SPIDERS / ROACHES

OBJECT

TESTING ULTRASONIC PEST REPELLER AGAINST ANTS / SPIDERS / ROACHES IN LABORATORY ENVIRONMENT. CONDUCTING OBSERVATIONS IN TOTAL 11 DAYS PERIOD, INCLUDING 2 DAYS PRELIMINARY TEST, 7 DAYS DURING TEST AND 2 DAYS POST TEST. THIS IS TO MEASURE THE EFFICACY OF HIGH-FREQUENCY SOUND AS A PEST MANAGEMENT TOOL. BOTH FREQUENCY AND SOUND PRESSURE (dB) ARE IMPORTANT PARAMETERS.

MATERIALS

FORMULATIONS	BELL + HOWELL ULTRASONIC PEST REPELLER
TEST ARTHROPODS	HEALTHY ANTS, SPIDERS & ROACHES
APPLICATION DEVICES	BELL + HOWELL ULTRASONIC PEST REPELLER
TESTING CHAMBER	SEE BELOW DIAGRAM

METHODS

Summary

8.5 feet long plastic tunnel is made to connect two chambers on each side. Each chamber is 4 feet (L) x 4 feet (W) x 1.5 feet (H). Ultrasonic Pest Repeller is placed at Chamber A, Chamber B has no ultrasonic pest repeller. Both sides have equal amount of food and water. Ants, Spiders and Roaches will be recorded at 24 hour intervals for total 11 days (or 264 hours). The number of ants / spiders / roaches will be recorded in each chamber. Any ants / spiders / roaches are found in Chamber B (no ultrasonic pest repeller) will be counted as repelled. Any ants / spiders / roaches remain in Chamber A (with ultrasonic pest repeller) will be counted as not repelled.

To determine the efficacy of the Bell + Howell Ultrasonic Pest Repeller for repelling ants, spiders and roaches. This device is tested over a 24 hours interval and total 11 days (or 264 hours) period in a laboratory environment. The test was preceded by a two-day preliminary test to ensure that the test apparatus and the selected food functioned properly.

Test sample


The test sample will be stored in a locked cabinet at ambient temperature and humidity until use in the study.



Preparation and Handling of Ants / Spiders / Roaches


20 ants, 20 spiders and 20 roaches will be used for both the control test and active test. As spiders are larger and far more aggressive than ants and roaches, they can, and often do, kill smaller pests like ants and roaches. Therefore the testing of spiders and ants/roaches must be conducted separately in different times.

Most of the spiders that have been studied so far seem to have similar dietary and digestive patterns. The first thing that should be stressed is that spiders will only eat living prey (or perhaps very recently killed ones), and the majority of spiders feed on insects, therefore recently dead roaches were used as food for spiders. In order to prevent spiders eat ants and roaches, the testing will be conducted separately, spiders in one testing chamber, ants and roaches together at the other chamber.



Construction of Test Chambers

The test will be conducted in two plastic chambers; each chamber is 4 feet (L) x 4 feet (W) x 1.5 feet (H). In between, there is a 8.5 feet long plastic tunnel to connect two chambers on each side, ants, spiders and roaches will each be given 11 days (264 hours) to move freely around Chamber A and Chamber B and inside the tunnel.



Food and Water Consumption

Data related to food and water consumption will be recorded in each chamber on a 24-hour interval throughout a 11-day (264 hours) period. The data will be used to identify changes in the eating behavior of ants, spiders and roaches due to the impact of the Ultrasonic Pest Repeller.

Fecal pellet counts

Record and trace fecal pellets of roaches on a 24 hours interval and 11 days (264 hours) period in each chamber. Neither fecal pellet nor urine spots for ants & spiders. This data will aid in understanding additional behavioral changes resulting from the Ultrasonic Pest Repeller.

Preliminary Testing

Ants / Spiders / Roaches activity will be documented before and after device installation. To observe general activity, a Preliminary Test will be conducted before the actual test to ensure the test apparatus and the selected food functioned properly. The Ultrasonic Pest Repeller will be turned "off" during preliminary testing. The release of Ants, Spiders and Roaches in Chamber A and Chamber B will be proportionate, with 50% of Ants, Spiders and Roaches distributed evenly in each chamber.



The Preliminary Test will consist of 20 ants, 20 spiders and 20 roaches. The pests will be each allotted 2 days (48 hours) to move freely around chamber A, Chamber B and inside the 8.5 feet long tunnel prior to the introduction of the Ultrasonic Pest Repeller.

Observation of Repellency (During Testing)

Release 50% of ants, spiders and roaches in Chamber A, and another 50% of ants, spiders and roaches in Chamber B. Turn On Ultrasonic Pest Repeller. Ants, Spiders and Roaches will be recorded at 24 hour intervals for 7 days (or 168 hours). Any ants, spiders and roaches that stay in the Chamber B (without ultrasonic pest repeller) will be counted as repelled. Any ants, spiders and roaches stay inside Chamber A (with ultrasonic pest repeller) will be counted as not repelled.

The During Testing will consist of 20 ants, 20 spiders and 20 roaches. The ants, spiders and roaches will each be given 7 days (168 hours) to move freely around Chamber A and Chamber B and inside the 8.5 feet long tunnel when the Ultrasonic Pest Repeller is ON.

Post Testing

To observe general activity, a post test will be conducted to ensure the test apparatus and the selected food functioned properly. Ultrasonic Pest Repeller will be turned OFF during post test. Release 50% of ants, spiders and roaches in Chamber A, release another 50% of ants, spiders and roaches in Chamber B.

The Post Test will consist of 20 ants, 20 spiders and 20 roaches. The ants, spiders and roaches are each given 2 days (48 hours) to move freely around chamber A, Chamber B and inside the 8.5 feet long tunnel when the Ultrasonic Pest Repeller is OFF.

No change is made in the ants, spiders and roaches population; the quantity should remain the same.

DATA ANALYSIS


The number of ants, spiders and roaches repelled and not repelled will be analyzed to determine the percent repellency.

All data should be recorded for 2 days (48 hours) Preliminary Test, 7 days (168 hours) of During Test, and 2 days (48 hours) of Post Test.




Testing device dimension (refer to below following figures)

Testing device for spider




Testing device for roaches and ants



Note: Distance between the two devices was about 20 meters

SGS



SPIDER TESTING DEVICE OVERLOOK



SGS UN-REMOVABLE SEAL LABEL



ROACHES AND ANTS DEVICE OVERLOOK



SGS UN-REMOVABLE SEAL LABEL

SGS


Test Result Data Measurement – Spider

SPIDER		PRELIMINARY TESTING		DURING TESTING								POST TESTING	
		SWITCH OFF		SWITCH ON								SWITCH OFF	
		48Hrs (-2 Day)	24Hrs (-1 Day)	24Hrs (1 Day)	48Hrs (2 Day)	72Hrs (3 Day)	96Hrs (4 Day)	120Hrs (5 Day)	144Hrs (6 Day)	168Hrs (7 Day)		24Hrs (+1 Day)	48Hrs (+2 Day)
Observe Date		1-Mar-12	12-Mar-12	13-Mar-12	14-Mar-12	15-Mar-12	16-Mar-12	17-Mar-12	18-Mar-12	19-Mar-12		20-Mar-12	21-Mar-12
Observe Time		10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM	10:30 AM		10:30 AM	10:30 AM
Chamber A (W/Pest Repeller)	quantity	10	10	10	2	1	0	0	0	0		8	11
	consumed food(unit)	39	39	0	1	0	0	0	0	0		19	4
	consumed water(ml)	39	39	18	10	13	8	9	3	8		40	53
Chamber B	quantity	10	10	19	18	19	20	20	20	20		12	9
	consumed food(unit)	3	3	4	4	5	6	6	7	7		4	4
	consumed water(ml)	28	28	24	59	36	56	39	47	51		51	46


Note:

- Canceled bread and white granulated sugar (as food) for spiders on 12-Mar-2012
- Each spider chambers provided 10 recently dead roaches as food for spiders on a daily basis
- Soaked sponges in the water, this helps spiders drinking water easier

SGS



SPIDER TESTING STATUS



SPIDER TESTING STATUS



Test Result Data Measurement –Roaches and Ants

ROACHES & ANTS			PRELIMINARY TESTING		DURING TESTING								POST-TESTING			
			SWITCH OFF		SWITCH ON								SWITCH OFF			
			48Hrs (2 Day)	24Hrs (1 Day)	24Hrs (1 Day)	48Hrs (2 Day)	72Hrs (3 Day)	96Hrs (4 Day)	120Hrs (5 Day)	144Hrs (6 Day)	168Hrs (7 Day)	+24Hrs (+1 Day)	+48Hrs (+2 Day)			
Observe Date			11-Mar-12		11-Mar-12											
Observe Time			10:30 AM		10:30 AM											
Chamber A (W/Pest Repeller)	quantity	ANTS	10	10	1	1	1	0	0	0	0	0	0	0	8	9
		ROACHES	10	0	2	1	1	0	0	0	0	0	0	0	11	8
	consumed food(g)		1	0	0	1	0	0	0	0	0	0	0	0	3	5
	consumed water(ml)		7	3	1	4	3	2	2	1	2	0	0	0	8	12
Chamber B	quantity	ANTS	10	19	19	19	19	20	20	20	20	20	20	20	12	11
		ROACHES	13	20	18	19	19	20	20	20	20	20	20	20	9	12
	consumed food(g)		1	2	4	5	5	2	2	3	4	4	4	4	2	5
	consumed water(ml)		5	6	8	14	14	5	5	9	13	10	10	10	7	10

- Feed bread & granulated sugar (as food) for ants and roaches.
- Equal amount of food & water were prepared at each chamber daily.

SGS



roaches and ants testing status



roaches and ants testing status




ROACHES FECAL PELLET RECORD REPORT

STAGE/ SWITCH ON/OFF		DATE	SUBJECT	CHAMBER : A (W/ PEST PELLER)	CHAMBER : B
PRELIMINARY TESTING	SWITCH OFF	11-Mar-12	roaches	Equal	Equal
		12-Mar-12	roaches	Equal	Equal
DURING TESTING	SWITCH ON	13-Mar-12	roaches	Very little	More
		14-Mar-12	roaches	Very little	More
		15-Mar-12	roaches	Very little	More
		16-Mar-12	roaches	No	More
		17-Mar-12	roaches	No	More
		18-Mar-12	roaches	No	More
		19-Mar-12	roaches	No	More
POST TESTING	SWITCH OFF	20-Mar-12	roaches	Equal	Equal
		21-Mar-12	roaches	Equal	Equal

Note:

- Only fecal pellet of roaches can be observed and witnessed, due to tiny and irregular sizes, fecal pellet were not easy to count, therefore quantity difference is described by three levels – little, very little and more
- There were no fecal pellet found for spiders & ants.

SGS




DEVICE OVERLOOK



ONLY ONE PEST REPELLER IN DEVICE



CHAMBER A



CHAMBER B




SGS SEAL LABEL




SGS SEAL LABEL


SGS




PEST REPELLER




PEST REPELLER



PEST REPELLER



PEST REPELLER




SGS SEAL ON PEST REPELLER



SGS SEAL ON PEST REPELLER


SGS




SPIDER DEVICE OVERLOOK




SPIDER DEVICE OVERLOOK




STATUS UNDER REPELLER SWITCHED OFF
(CHAMBER A)




STATUS UNDER REPELLER SWITCHED OFF
(CHAMBER B)




STATUS UNDER REPELLER SWITCHED
ON(CHAMBER A)



STATUS UNDER REPELLER SWITCHED
ON(CHAMBER B)




ROACHES AND ANTS DEVICE OVERLOOK




ROACHES AND ANTS DEVICE OVERLOOK



STATUS UNDER REPELLER SWITCHED
OFF(CHAMBER A)



STATUS UNDER REPELLER SWITCHED
OFF(CHAMBER B)




STATUS UNDER REPELLER SWITCHED
ON(CHAMBER A)




STATUS UNDER REPELLER SWITCHED
ON(CHAMBER B)

SGS




SOAKED SPONGE TO MEASURE WATER
CONSUMPTION FOR SPIDERS



SOAKED SPONGE TO MEASURE WATER
CONSUMPTION FOR SPIDERS



ROACHES AND ANTS WATER GROSS WEIGHT
CHECK



ROACHES AND ANTS RENOVATE WATER
WEIGHT




ROACHES AND ANTS FOOD GROSS WEIGHT
CHECK




ROACHES AND ANTS RENOVATE FOOD WEIGHT



SPIDER STATUS




SPIDER STATUS



ROACHES AND ANTS STATUS



ROACHES AND ANTS STATUS



ROACHES AND ANTS STATUS



ROACHES AND ANTS STATUS



Note

In accordance with Client's instructions, the Company's involvement has been limited to witnessing/observing a third party's intervention(s) at the facilities where the intervention(s) took place. The Company's sole responsibility was to be present at the time of the third party's intervention(s) and to confirm and report the occurrence of the intervention(s). The Company is not responsible for methods applied, the qualifications, actions or omissions of the third party's personnel or the results or effectiveness of the intervention(s).

SGS Inspector. ZHIYONG LIU Factory Representative: _____

****End of Report****

2012 SPIDERS / ANTS / ROACHES TEST REPORT RESULT ANALYSIS

March 27, 2012

Construction of Test Chamber:

- The test was conducted in two plastic chambers. Each chamber was 4' (L) x 4' (W) x 1.5' (H).
- Pest Repeller was placed in chamber A. There was no pest repeller in Chamber B.
- In between, there was a 8.5 feet long plastic tunnel. The tunnel was "curved" and two chambers were designed in Hi-Lo level. The curved and Hi-Lo tunnel design was to further ensure ultrasonic sound wave would not enter from chamber A into chamber B since sound wave was directional.
- All edges were sealed securely with SGS unbreakable labels. Only SGS inspector could open the chambers to count ants / spiders / roaches quantities, weighted food and water and replaced new seals on a daily basis.
- Total 20 ants, 20 spiders and 20 roaches were used, and tested separately in different chambers.
- Released 50% of ants / spiders / roaches in chamber A, and another 50% of ants / spiders / roaches in Chamber B at the beginning of the test.
- There were 3 testing stages;
 - Preliminary Testing: 2 days = 48 hours, pest repeller was OFF
 - During Testing: 7 days = 168 hours, pest repeller was ON
 - Post Testing: 2 days = 48 hours, pest repeller was OFF

Test Result Analysis (see page 8)

Spiders


- Preliminary Testing: 50% spiders stayed in Chamber A, 50% spiders stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 90% ~ 95% spiders stayed away from Chamber A, Day 4 ~ Day 7, 100% spiders stayed away from Chamber A. Pest repeller was switched ON in Chamber A during testing.
- Post Testing: 40% ~ 55% spiders returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand spiders' eating behavior under the influence of ultrasonic sound.

Ants - Test Result Analysis (see page 10)

- Preliminary Testing: 50% ants stayed in Chamber A, 50% ants stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 95% ants stayed away from Chamber A, Day 4 ~ Day 7, 100% ants stayed away from Chamber A. Pest repeller was switched on in Chamber A during testing.
- Post Testing: 40% ~ 45% ants returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand ant's eating behavior under the influence of ultrasonic sound.

BELL + HOWELL ULTRASONIC PEST REPELLER

EFFICACY TEST REPORT





TEST REPORT

Report Number: 140515021GZU-002

Issued Date: July 7, 2014

Applicant : INTELLITEC INTERNATIONAL INC.
Address : Unit201 Yuekai Commercial Building,NO28,Dongyuan Road,Changping Town,Dongguan
Manufacturer : INTELLITEC INTERNATIONAL INC.
Address : Unit201 Yuekai Commercial Building,NO28,Dongyuan Road,Changping Town,Dongguan

Specimen Description

Product : BELL + HOWELL Ultrasonic Pest Repeller
Style Number : 50167
Sample Received Date : Provided by applicant on May 16,2014
Quantity of Sample : 1 piece

Test Content

Date Test Conducted : From May 16, 2014 to May 27, 2014
Test Requested : Witness for performance testing
- Ants, Spiders and Roaches
Test Standard/Method : According to client's requirement.
Test Location : Dongguan, Guangdong, China

Test Results : Please see the following pages for details

Remark: When determining the test conclusion, the Measurement Uncertainty of test has been considered.

Prepared by:

Reviewed by:

Leo Lin

Leo Lin
Engineer

Sam Lin

Sam Lin
Supervisor

Page 1 of 10

This report is for the exclusive use of Intertek's Client and is provided pursuant to the agreement between Intertek and its Client. Intertek's responsibility and liability are limited to the terms and conditions of the agreement. Intertek assumes no liability to any party, other than to the Client in accordance with the agreement, for any loss, expense or damage occasioned by the use of this report. Only the Client is authorized to permit copying or distribution of this report and then only in its entirety. Any use of the Intertek name or one of its marks for the sale or advertisement of the tested material, product or service must first be approved in writing by Intertek. The observations and test results in this report are relevant only to the sample tested. This report by itself does not imply that the material, product, or service is or has ever been under an Intertek certification program. And in this report * means the test item is subcontracted.




INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

SAMPLE INFORMATION

One BELL + HOWELL Ultrasonic Pest Repeller were received in good condition and could work normally.



***** End of Page *****

Page 2 of 10

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02 1-S/F & Room 01. E101/E501/E601/E701/E801 No 7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9686 Fax: (86-20) 3205 7538
Website: www.intertek-etisemko.com (GZPERF-BRAND V0 (August 16, 2012))

BHH,LLC 002554



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST OBJECT

Testing Ultrasonic Pest Repeller against Ants, Spiders and Roaches in laboratory environment, conducting observations in total 11 days period, including 2 days Preliminary test, 7 days During test and 2 days Post test. This is to measure the efficacy of high-frequency sound as a pest management tool. Both frequency and sound pressure (db) are important parameters.

TEST CONDITION

The test samples were stored in a locked cabinet at ambient temperature and humidity until use in testing. And during testing test chambers were stored at ambient temperature and humidity.

TEST PROCEDURE

1. Prepare test chambers, test pests and food/water

Test chambers consisted of two plastic chambers, chamber A (with ultrasonic pest repeller) and Chamber B (no ultrasonic pest repeller), each chamber is 4 feet (L) x 4 feet (W) x 1.5 feet (H). There is an 8.5 feet long plastic tunnel to connect the two chambers. See appendix III for reference.

Test chambers were sealed by Intertek sealed label. After daily check, replace with new sealed label.

Test pests consisted of 10 ants, 10 spiders and 10 roaches. All of them were adult and healthy.

Placed an equal amount of food and water in chamber A and chamber B. Used granulated sugar as food. Socked sponges in the water, this helps test pests drinking water easier. 20g food and 40g water were prepared in each chamber daily during the test.

2. Preliminary Testing

Test pests' activity was documented before and after device installation. To observe general activity, a Preliminary Testing was conducted before the actual test to ensure the test apparatus and the selected food functioned properly. The Ultrasonic Pest Repeller was turned OFF during preliminary testing. The release of test pests in Chamber A and Chamber B will be proportionate, with 50% of Ants, Spiders and Roaches distributed evenly in each chamber. The test pests were given 2 days (48 hours) to move freely around chamber A, Chamber B and the tunnel prior to the introduction of the Ultrasonic Pest Repeller.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST PROCEDURE (continued)

3. Observation of Repellency (During Testing)

Turn On Ultrasonic Pest Repeller. Test pests were recorded at a 24 hours intervals for 7 days (or 168 hours). Any test pests that stay in the Chamber B (without ultrasonic pest repeller) were counted as repelled. Any test pests stay in Chamber A (with ultrasonic pest repeller) were counted as not repelled. The test pests were given 7 days (168 hours) to move freely around Chamber A and Chamber B and the tunnel when the Ultrasonic Pest Repeller is ON.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

4. Post Testing

To observe general activity, a post testing was conducted to ensure the test apparatus and the selected food functioned properly. Ultrasonic Pest Repeller was turned OFF during post testing. The test pests were given 2 days (48 hours) to move freely around chamber A, Chamber B and the tunnel.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

5. Testing record

During total of 11 days (264 hours) testing period, record below items at a 24hours interval.

1. The quantity of ants/spiders/roaches in each chamber. No change was made in the rats/mice population.
2. The consumption of food and water in each chamber.
3. The fecal pellet counts & Urine spots in each chamber.

***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST RESULT

Spider/Roaches/Ants				PRELIMINARY TESTING		DURING TESTING												POST TESTING		
				SWITCH OFF		SWITCH ON												SWITCH OFF		
				-48Hrs (-2 Day)	-24Hrs (-1 Day)	24Hrs (1 Day)	48Hrs (2 Day)	72Hrs (3 Day)	96Hrs (4 Day)	120Hrs (5 Day)	144Hrs (6 Day)	168Hrs (7 Day)	168Hrs (7 Day)	168Hrs (7 Day)	168Hrs (7 Day)	+24Hrs (+1 Day)	+48Hrs (+2 Day)			
Chamber A (W/Pest Repeller)	Observe Date			17-May-14	18-May-14	19-May-14	20-May-14	21-May-14	22-May-14	23-May-14	24-May-14	25-May-14	26-May-14	27-May-14						
	Observe Time			11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM						
	Quantity	Spider	3	3	3	1	2	1	1	0	0	0	0	3	4					
		Roaches	7	6	5	0	1	0	0	0	0	0	0	2	5					
	Consumed food(g)	Ants	4	6	4	1	0	1	0	1	0	0	0	5	7					
		Consumed water(ml)	0.6	1.6	0	0	0	0	0.2	0	0	0	0.2	0.2	0.6					
Chamber B	Consumed food(g)			3.2	9.2	6.2	2.6	3	1.6	2.8	1.6	1.8	4.6	4.6						
	Quantity	Spider	7	7	7	9	8	9	9	9	10	10	7	6						
		Roaches	3	4	5	10	9	10	10	10	10	10	8	5						
	Consumed food(g)	Ants	6	4	6	9	10	9	10	9	10	10	4	3						
		Consumed water(ml)	0.2	1.0	0.2	0.2	0.4	0.8	0.6	0.4	0.6	0.6	0.4	0.2						
	Consumed food(g)			1.4	8.0	9.2	4.4	5.2	3.4	4.0	4.4	3.6	3.6	3.0						

Note: Found 1 spider, 1 roach & 2 ants dead on 17-May-2014; 1 roach & 2 ants dead on 18-May-2014, 1 roach dead on 19-May-2014. Added new spiders, roaches & ants next day.

***** End of Page *****

Page 5 of 10

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9658 Fax: (86-20) 3205 7538
Website: www.intertek-et.com.cn GZPERF-BRAND VD (August 16, 2012)

BHH,LLC 002557



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST RESULT (Continued)

For Roaches fecal pellet & urine spots

STAGE/ SWITCH ON/OFF		DATE	SUBJECT	CHAMBER A (W/ PEST PELLER)	CHAMBER B
PRELIMINARY TESTING	SWITCH OFF	17-May-14	ROACHES	Equal	Equal
		18-May-14	ROACHES	Equal	Equal
DURING TESTING	SWITCH ON	19-May-14	ROACHES	Equal	Equal
		20-May-14	ROACHES	Little	More
		21-May-14	ROACHES	Little	More
		22-May-14	ROACHES	Little	More
		23-May-14	ROACHES	Little	More
		24-May-14	ROACHES	Little	More
		25-May-14	ROACHES	Little	More
POST TESTING	SWITCH OFF	26-May-14	ROACHES	Little	More
		27-May-14	ROACHES	Equal	Equal

Note:

Fecal pellet and urine are observed and witnessed by naked eye. Due to tiny and irregular sizes, Ants, Spiders and Roaches' fecal pellet & urine spots are not easy to count, therefore quantity difference is described by three levels-little, very little and more.

***** End of Page *****

Page 6 of 10

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel (86-20) 8213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etisemko.com GZPERF-BRAND V0 (August 16, 2012)


BHH,LLC 002558



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

Appendix I




***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

Appendix II




***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

Appendix III





INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

REVISION SUMMARY

Date	Project Handler Reviewer	Page	Description of Change
2014-7-7			Initial release

***** End of Report *****

Page 10 of 10

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 6213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etisemko.com GZPERF-BRAND V0 (August 16, 2012)

BHH,LLC 002562

2015 RATS/ MICE TEST REPORT RESULT ANALYSIS

July 7, 2014

Construction of Test Chamber:

- The test was conducted in two plastic chambers. Each chamber was 4' (L) x 4' (W) x 2' (H).
- Ultrasonic Pest Repeller was placed in chamber A. There was no Ultrasonic pest repeller in Chamber B.
- In between, there was an 8.5 feet long plastic tunnel. The tunnel was "curved" and two chambers were designed in Hi-Lo level. The curved and Hi-Lo tunnel design was to further ensure ultrasonic sound wave would not enter from chamber A into chamber B since sound wave was directional.
- All edges were sealed securely with Intertek unbreakable labels. Only Intertek inspector could open the chambers to rats/ mice quantities, weighted food and water and replaced new seals on a daily basis.
- Total 10 rats and 10 mice were used, and tested separately in different chambers.
- Released 50% of rats / mice in chamber A, and another 50% of rats / mice in Chamber B at the beginning of the test.
- There were 3 testing stages;
 - Preliminary Testing: 2 days = 48 hours, pest repeller was OFF
 - During Testing: 7 days = 168 hours, pest repeller was ON
 - Post Testing: 2 days = 48 hours, pest repeller was OFF

Test Result Analysis

Rats (see page 5)

- Preliminary Testing: 40%~60% rates stayed in Chamber A, 60%~40% rates stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 60%~90% rats stayed away from Chamber A, Day 4 ~ Day 7, 100% rates stayed away from Chamber A. Pest repeller was switched ON in Chamber A during testing.
- Post Testing: 30% ~ 60% rates returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand rates' eating behavior under the influence of ultrasonic sound.

Mice – (see page 6)

- Preliminary Testing: 40%~50% Mice stayed in Chamber A, 60%~50% Mice stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 80% ~ 90% mice stayed away from Chamber A, Day 4 ~ Day 7, 90% ~ 100% mice stayed away from Chamber A. Pest repeller was switched on in Chamber A during testing.
- Post Testing: 40% ~ 60% Mice returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand ant's eating behavior under the influence of ultrasonic sound.

Fecal Pellets Count (see page 7)

- Lab technician traced and recorded pest fecal pellets on a daily basis, this helped to further understand pest's activities and behaviors under the influence of ultrasonic sound.
- Lab technician could only trace fecal pellets and urine spot was observed:
 - When pest repeller was switched on During Testing; fecal pellets appeared to be much LESS quantities in Chamber A.
 - When pest repeller was switched off during Preliminary and Post Testing, fecal pellet quantities appeared to be more EVEN in two chambers.
- There was neither fecal pellet nor urine spot was found from rats and mice during the entire testing period.



TEST REPORT

Report Number: 140515021GZU-001

Issued Date: July 7, 2014

Applicant : INTELLITEC INTERNATIONAL INC.
Address : Unit 201 Yuekai Commercial Building, NO28, Dongyuan Road, Changping Town, Dongguan
Manufacturer : INTELLITEC INTERNATIONAL INC.
Address : Unit 201 Yuekai Commercial Building, NO28, Dongyuan Road, Changping Town, Dongguan

Specimen Description

Product : BELL + HOWELL Ultrasonic Pest Repeller
Style Number : 50167
Sample Received Date : Provided by applicant on May 16, 2014
Quantity of Sample : 2 pieces.

Test Content

Date Test Conducted : From May 16, 2014 to May 27, 2014
Test Requested : Witness for performance testing – Rats and Mice
Test Standard/Method : According to client's requirements.
Test Location : Dongguan, Guangdong, China

Test Results : See the following pages for details.

Remark: When determining the test conclusion, the Measurement Uncertainty of test has been considered.

Prepared by:

Reviewed by:

Leo Lin

Leo Lin
Engineer

Sam Lin

Sam Lin
Supervisor

Page 1 of 14

This report is for the exclusive use of Intertek's Client and is provided pursuant to the agreement between Intertek and its Client. Intertek's responsibility and liability are limited to the terms and conditions of the agreement. Intertek assumes no liability to any party, other than to the Client in accordance with the agreement, for any loss, expense or damage occasioned by the use of this report. Only the Client is authorized to permit copying or distribution of this report and then only in its entirety. Any use of the Intertek name or one of its marks for the sale or advertisement of the tested material, product or service must first be approved in writing by Intertek. The observations and test results in this report are relevant only to the sample tested. This report by itself does not imply that the material, product, or service is or has ever been under an Intertek certification program. And in this report * means the test item is subcontracted.




INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

SAMPLE INFORMATION

Two BELL + HOWELL Ultrasonic Pest Repeller were received in good condition and could work normally.



***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

TEST OBJECT

Test Ultrasonic Pest Repeller against rats and mice in laboratory environment, conducting observations in total 11 days period, including 2 days Preliminary test, 7 days During test and 2 days Post test. This is to measure the efficacy of high-frequency sound as a pest management tool.

Both frequency and sound pressure (db) are important parameters.

TEST CONDITION

The test samples were stored in a locked cabinet at ambient temperature and humidity until use in testing. And during testing test chambers were stored at ambient temperature and humidity.

TEST PROCEDURE

1. Prepare test Chamber, rats/mice and food/water

Test chambers of rat consisted of two plastic chambers, chamber A (with ultrasonic pest repeller) and Chamber B (no ultrasonic pest repeller), each chamber is 4 feet (L) x 4 feet (W) x 2 feet (H). There is an 8.5 feet long plastic tunnel to connect these two chambers. Test chambers of mice are same except for the height of chamber is 1.5 feet. See appendix III for reference.

Test chambers were sealed by Intertek sealed label. After daily check, replace with new sealed label.

Prepared 10 rats and 10 mice. All of them were adult and healthy. As rats are larger and far more aggressive than mice, they can, and often do, kill mice. Therefore the testing of rats and mice was conducted separately.

Placed an equal amount of food and water in chamber A and chamber B. Used the mixture of rice, corn flour and soybean particle as food for rats and mice and used tap water. During the test, 500g food and 400g water for rats, 100g food and 100g water for mice were prepared in each chamber daily.

2. Preliminary Testing

Rats and mice's activity was documented before and after device installation. To observe general activity, conducted a Preliminary Testing before the actual test to ensure the test apparatus and the selected food functioned properly. The Ultrasonic Pest Repeller was turned OFF during preliminary testing. The release of rats and mice in Chamber A and Chamber B was proportionate, with 50% of rats and mice distributed evenly in each chamber. Rats and mice were given 2 days (48 hours) to move freely around chamber A, Chamber B and the tunnel prior to the introduction of the Ultrasonic Pest Repeller.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

***** End of Page *****

Page 3 of 14

intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No 7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City. GETDD Guangzhou Tel: (86-20) 8213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etlisenk.com GZPERF-BRAND V0 (August 16, 2012)



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

TEST PROCEDURE (continued)

3. Observation of Repellency (During Testing)

Turn On Ultrasonic Pest Repeller. Rats and mice were recorded at 24 hour intervals for 7 days (or 168 hours). Any rats and mice that stay in the Chamber B (without ultrasonic pest repeller) were counted as repelled. Any rats and mice stay in Chamber A (with ultrasonic pest repeller) were counted as not repelled. Rats and mice were given 7 days (168 hours) to move freely around Chamber A and Chamber B and the tunnel when the Ultrasonic Pest Repeller is ON.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

4. Post Testing

To observe general activity, a post testing was conducted to ensure the test apparatus and the selected food functioned properly. Ultrasonic Pest Repeller was turned OFF during post testing. Rats and mice were given 2 days (48 hours) to move freely around chamber A, Chamber B and the tunnel.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

5. Testing record

During total of 11 days (264 hours) testing period, record below items at a 24hours interval.

1. The quantity of rats/mice in each chamber. No change was made in the rats/mice population.
2. The consumption of food and water in each chamber.
3. The fecal pellet counts & Urine spots in each chamber.

***** End of Page *****



INTELLITEC
INTERNATIONAL INC.

140515021GZU-001

TEST RESULT

RATS			DURING TESTING										POST TESTING	
			PRELIMINARY TESTING		SWITCH ON									
			SWITCH OFF		SWITCH OFF									
Observe Date	Observe Time	Quantity	-48Hrs	-24Hrs	24Hrs	48Hrs	72Hrs	96Hrs	120Hrs	144Hrs	168Hrs	+24Hrs	+48Hrs	
		Consumed food(g)	(-2 Day)	(-1 Day)	(1 Day)	(2 Day)	(3 Day)	(4 Day)	(5 Day)	(6 Day)	(7 Day)	(+1 Day)	(+2 Day)	
		Consumed water(ml)	17-May-14	18-May-14	19-May-14	20-May-14	21-May-14	22-May-14	23-May-14	24-May-14	25-May-14	26-May-14	27-May-14	
			10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	
			4	6	4	2	1	0	0	0	0	3	6	
Chamber A (W/Pest Repeller)	Observe Time	Consumed food(g)	59.0	54.2	42.2	26.2	39.0	24.4	31.8	43.8	41.6	41.0	44.0	
		Consumed water(ml)	217.8	161.2	124.0	34.0	46.8	41.0	56.0	71.8	54.6	58.2	54.0	
			6	4	6	8	9	10	10	10	10	7	4	
Chamber B	Observe Time	Quantity	56.4	61.8	55.2	82.8	88.4	80.2	76.4	83.4	70.0	28.0	24.0	
		Consumed food(g)												
		Consumed water(ml)	225.8	173.8	153.8	181.6	149.6	141.2	127.6	150.6	128.4	17.6	23.6	

***** End of Page *****

Page 5 of 14

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDO Guangzhou Tel: (86-20) 8213 9698 Fax: (86-20) 3205 7538
Website: www.intertek-elisenko.com GZPERF-BRAND V0 (August 16, 2012)

BHH,LLC 002569



INTELLITEC
INTERNATIONAL INC.

140515021GZU-001

TEST RESULT (Continued)

MICE			PRELIMINARY TESTING		DURING TESTING										POST TESTING	
			SWITCH OFF		SWITCH ON										SWITCH OFF	
			-48Hrs	-24Hrs	24Hrs	48Hrs	72Hrs	96Hrs	120Hrs	144Hrs	168Hrs	+24Hrs	+48Hrs			
			(-2 Day)	(-1 Day)	(1 Day)	(2 Day)	(3 Day)	(4 Day)	(5 Day)	(6 Day)	(7 Day)	(+1 Day)	(+2 Day)			
Observe Date			17-May-14	18-May-14	19-May-14	20-May-14	21-May-14	22-May-14	23-May-14	24-May-14	25-May-14	26-May-14	27-May-14			
Observe Time			10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM	10:30AM			
Chamber A (W/Pest Repeller)	Quantity		4	5	2	0	1	1	0	0	0	6	4			
	Consumed food(g)		32.8	35.8	22.8	15	15.6	14.2	12.2	11.8	10.6	18.2	14.6			
	Consumed water(ml)		18.2	26.2	11.8	8.4	9.0	5.6	10.8	6.4	15.8	19.4	18.2			
Chamber B	Quantity		6	5	8	10	9	9	10	10	10	4	6			
	Consumed food(g)		15.8	40.0	23.6	22.8	29.6	26.0	22.4	19.8	24.2	19.4	15.2			
	Consumed water(ml)		20.4	32.6	17.4	15.8	12.8	17.2	28.4	29.8	32.6	11.4	13.2			

***** End of Page *****

Page 6 of 14

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9698 Fax: (86-20) 3205 7538
Website: www.intertek-elisenko.com GZPERF-BRAND V0 (August 16, 2012)

BHH, LLC 002570



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

TEST RESULT (Continued)

For Rats/Mice fecal pellet & urine spots

STAGE/ SWITCH ON/OFF		DATE	SUBJECT	CHAMBER A (W/ PEST PELLER)	CHAMBER B
PRELIMINARY TESTING	SWITCH OFF	17-May-14	RATS	Equal	Equal
			MICE	Equal	Equal
		18-May-14	RATS	Equal	Equal
			MICE	Equal	Equal
DURING TESTING	SWITCH ON	19-May-14	RATS	Equal	Equal
			MICE	Equal	Equal
		20-May-14	RATS	Little	More
			MICE	Little	More
		21-May-14	RATS	Little	More
			MICE	Little	More
		22-May-14	RATS	Little	More
			MICE	Little	More
		23-May-14	RATS	Little	More
			MICE	Little	More
		24-May-14	RATS	Little	More
			MICE	Little	More
POST TESTING	SWITCH OFF	26-May-14	RATS	Equal	Equal
			MICE	More	Little
		27-May-14	RATS	Equal	Equal
			MICE	Equal	Equal

Note:

Fecal pellet and urine are observed and witnessed by naked eye. Due to tiny and irregular sizes, rats and mice's fecal pellet & urine spots are not easy to count, therefore quantity difference is described by three levels-little, very little and more.

***** End of Page *****

Page 7 of 14

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-5/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etisemko.com GZPERF-BRAND V0 (August 16, 2012)


BHH,LLC 002571



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

Appendix I



***** End of Page *****


Page 8 of 14

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-S/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etsemko.com GZPERF-BRAND V0 (August 16, 2012)

BHH,LLC 002572

IntertekINTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

Appendix I (Continued)

***** End of Page *****

Page 9 of 14

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-6/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GE'DD Guangzhou Tel: (86-20) 8213 9686 Fax: (86-20) 3205 7538
Website: www.intertek-etlsemko.com GZPERF-BRAND V0 (August 16, 2012)


BHH,LLC 002573



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

Appendix II




***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

Appendix II (Continued)



***** End of Page *****

Page 11 of 14

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-S/F & Room 01, E101/E501/E601/E701/E801 No 7-2, Guang Dong Software Science Park, Caipin Road Guangzhou
Science City GETDD Guangzhou Tel: (86-20) 8213 9688 Fax: (86-20) 3206 7538
Website: www.intertek-etlsemko.com GZPERF-BRAND V0 (August 16 2012)


BHH,LLC 002575




INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

Appendix III



Testing device dimension of Rats



Testing device dimension of Mice


***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

Appendix III (Continued)



***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-001

REVISION SUMMARY

Date	Project Handler Reviewer	Page	Description of Change
2014-7-7			Initial release

*******End of Report*******

Page 14 of 14

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City. GETDD Guangzhou Tel: (86-20) 8213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etlseriko.com GZPERF-BRAND V0 (August 16, 2012)

BHH,LLC 002578

2014 SPIDERS / ANTS / ROACHES TEST REPORT RESULT ANALYSIS

July 7, 2014

Construction of Test Chamber:

- The test was conducted in two plastic chambers. Each chamber was 4' (L) x 4' (W) x 1.5' (H).
- Pest Repeller was placed in chamber A. There was no pest repeller in Chamber B.
- In between, there was a 8.5 feet long plastic tunnel. The tunnel was "curved" and two chambers were designed in Hi-Lo level. The curved and Hi-Lo tunnel design was to further ensure ultrasonic sound wave would not enter from chamber A into chamber B since sound wave was directional.
- All edges were sealed securely with Intertek unbreakable labels. Only Intertek inspector could open the chambers to count ants / spiders / roaches quantities, weighted food and water and replaced new seals on a daily basis.
- Total 10 ants, 10 spiders and 10 roaches were used, and tested separately in different chambers.
- Released 50% of ants / spiders / roaches in chamber A, and another 50% of ants / spiders / roaches in Chamber B at the beginning of the test.
- There were 3 testing stages;
 - Preliminary Testing: 2 days = 48 hours, pest repeller was OFF
 - During Testing: 7 days = 168 hours, pest repeller was ON
 - Post Testing: 2 days = 48 hours, pest repeller was OFF

Test Result Analysis

Spiders (see page 5)

- Preliminary Testing: 30% spiders stayed in Chamber A, 70% spiders stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 70%~80% spiders stayed away from Chamber A, Day 4 ~ Day 7, 90%~100% spiders stayed away from Chamber A. Pest repeller was switched ON in Chamber A during testing.
- Post Testing: 30% ~ 40% spiders returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand spiders' eating behavior under the influence of ultrasonic sound.

Roaches – Test Result Analysis (see page 5)

- Preliminary Testing: 60%~70% ants stayed in Chamber A, 40%~30% ants stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 50 %~100% roaches stayed away from Chamber A, Day 4 ~ Day 7, 100% roaches stayed away from Chamber A. Pest repeller was switched on in Chamber A during testing.
- Post Testing: 30%~40% roaches returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand roaches' eating behavior under the influence of ultrasonic sound.

Ants – Test Result Analysis (see page 5)

- Preliminary Testing: 40%~60% ants stayed in Chamber A, 60%~40% ants stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 60%~100% ants stayed away from Chamber A, Day 4 ~ Day 7, 100% ants stayed away from Chamber A. Pest repeller was switched on in Chamber A during testing.
- Post Testing: 60% ~ 70% ants returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand ant's eating behavior under the influence of ultrasonic sound.

Fecal Pellets Count (see page 12)

- Lab technician traced and recorded pest fecal pellets on a daily basis, this helped to further understand pest's activities and behaviors under the influence of ultrasonic sound.
- Lab technician could only trace fecal pellets from roaches, but no urine spot was observed:
 - When pest repeller was switched on During Testing; fecal pellets appeared to be much LESS quantities in Chamber A.
 - When pest repeller was switched off during Preliminary and Post Testing, fecal pellet quantities appeared to be more EVEN in two chambers.
- There was neither fecal pellet nor urine spot was found from spiders and ants during the entire testing period.

Ants – Test Result Analysis (see page 5)

- Preliminary Testing: 40%~60% ants stayed in Chamber A, 60%~40% ants stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 60%~100% ants stayed away from Chamber A, Day 4 ~ Day 7, 100% ants stayed away from Chamber A. Pest repeller was switched on in Chamber A during testing.
- Post Testing: 60% ~ 70% ants returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand ant's eating behavior under the influence of ultrasonic sound.

Fecal Pellets Count (see page 12)

- Lab technician traced and recorded pest fecal pellets on a daily basis, this helped to further understand pest's activities and behaviors under the influence of ultrasonic sound.
- Lab technician could only trace fecal pellets from roaches, but no urine spot was observed:
 - When pest repeller was switched on During Testing; fecal pellets appeared to be much LESS quantities in Chamber A.
 - When pest repeller was switched off during Preliminary and Post Testing, fecal pellet quantities appeared to be more EVEN in two chambers.
- There was neither fecal pellet nor urine spot was found from spiders and ants during the entire testing period.