

BELL + HOWELL ULTRASONIC PEST REPELLER

EFFICACY TEST REPORT





TEST REPORT

Report Number: 140515021GZU-002

Issued Date: July 7, 2014

Applicant : INTELLITEC INTERNATIONAL INC.
Address : Unit201 Yuekai Commercial Building,NO28,Dongyuan Road,Changping Town,Dongguan
Manufacturer : INTELLITEC INTERNATIONAL INC.
Address : Unit201 Yuekai Commercial Building,NO28,Dongyuan Road,Changping Town,Dongguan

Specimen Description

Product : BELL + HOWELL Ultrasonic Pest Repeller
Style Number : 50167
Sample Received Date : Provided by applicant on May 16,2014
Quantity of Sample : 1 piece

Test Content

Date Test Conducted : From May 16, 2014 to May 27, 2014
Test Requested : Witness for performance testing
- Ants, Spiders and Roaches
Test Standard/Method : According to client's requirement.
Test Location : Dongguan, Guangdong, China

Test Results : Please see the following pages for details

Remark: When determining the test conclusion, the Measurement Uncertainty of test has been considered.

Prepared by:

Reviewed by:

Leo Lin

Leo Lin
Engineer

Sam Lin

Sam Lin
Supervisor

Page 1 of 10

This report is for the exclusive use of Intertek's Client and is provided pursuant to the agreement between Intertek and its Client. Intertek's responsibility and liability are limited to the terms and conditions of the agreement. Intertek assumes no liability to any party, other than to the Client in accordance with the agreement, for any loss, expense for damage occasioned by the use of this report. Only the Client is authorized to permit copying or distribution of this report and then only in its entirety. Any use of the Intertek name or one of its marks for the sale or advertisement of the tested material, product or service must first be approved in writing by Intertek. The observations and test results in this report are relevant only to the sample tested. This report by itself does not imply that the material, product, or service is or has ever been under an Intertek certification program. And in this report " means the test item is subcontracted.




INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

SAMPLE INFORMATION

One BELL + HOWELL Ultrasonic Pest Repeller were received in good condition and could work normally.



***** End of Page *****

Page 2 of 10

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No 7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etisemiko.com GZPERF-BRAND V0 (August 16, 2012)

BHH,LLC 002554



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST OBJECT

Testing Ultrasonic Pest Repeller against Ants, Spiders and Roaches in laboratory environment, conducting observations in total 11 days period, including 2 days Preliminary test, 7 days During test and 2 days Post test. This is to measure the efficacy of high-frequency sound as a pest management tool. Both frequency and sound pressure (db) are important parameters.

TEST CONDITION

The test samples were stored in a locked cabinet at ambient temperature and humidity until use in testing. And during testing test chambers were stored at ambient temperature and humidity.

TEST PROCEDURE

1. Prepare test chambers, test pests and food/water

Test chambers consisted of two plastic chambers, chamber A (with ultrasonic pest repeller) and Chamber B (no ultrasonic pest repeller), each chamber is 4 feet (L) x 4 feet (W) x 1.5 feet (H). There is an 8.5 feet long plastic tunnel to connect the two chambers. See appendix III for reference.

Test chambers were sealed by Intertek sealed label. After daily check, replace with new sealed label.

Test pests consisted of 10 ants, 10 spiders and 10 roaches. All of them were adult and healthy.

Placed an equal amount of food and water in chamber A and chamber B. Used granulated sugar as food. Socked sponges in the water, this helps test pests drinking water easier. 20g food and 40g water were prepared in each chamber daily during the test.

2. Preliminary Testing

Test pests' activity was documented before and after device installation. To observe general activity, a Preliminary Testing was conducted before the actual test to ensure the test apparatus and the selected food functioned properly. The Ultrasonic Pest Repeller was turned OFF during preliminary testing. The release of test pests in Chamber A and Chamber B will be proportionate, with 50% of Ants, Spiders and Roaches distributed evenly in each chamber. The test pests were given 2 days (48 hours) to move freely around chamber A, Chamber B and the tunnel prior to the introduction of the Ultrasonic Pest Repeller.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST PROCEDURE (continued)

3. Observation of Repellency (During Testing)

Turn On Ultrasonic Pest Repeller. Test pests were recorded at a 24 hours intervals for 7 days (or 168 hours). Any test pests that stay in the Chamber B (without ultrasonic pest repeller) were counted as repelled. Any test pests stay in Chamber A (with ultrasonic pest repeller) were counted as not repelled. The test pests were given 7 days (168 hours) to move freely around Chamber A and Chamber B and the tunnel when the Ultrasonic Pest Repeller is ON.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

4. Post Testing

To observe general activity, a post testing was conducted to ensure the test apparatus and the selected food functioned properly. Ultrasonic Pest Repeller was turned OFF during post testing. The test pests were given 2 days (48 hours) to move freely around chamber A, Chamber B and the tunnel.

The fecal pellet counts & Urine spots were cleaned daily (24 hours).

5. Testing record

During total of 11 days (264 hours) testing period, record below items at a 24hours interval.

1. The quantity of ants/spiders/roaches in each chamber. No change was made in the rats/mice population.
2. The consumption of food and water in each chamber.
3. The fecal pellet counts & Urine spots in each chamber.

***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST RESULT

Spider/Roaches/Ants				DURING TESTING											POST TESTING	
				PRELIMINARY TESTING		SWITCH ON										
				SWITCH OFF		48Hrs	24Hrs	48Hrs	72Hrs	96Hrs	120Hrs	144Hrs	168Hrs	+24Hrs	+48Hrs	
					-48Hrs	-24Hrs	(-2 Day)	(1 Day)	(2 Day)	(3 Day)	(4 Day)	(5 Day)	(6 Day)	(7 Day)	(+1 Day)	(+2 Day)
Observe Date				17-May-14	18-May-14	19-May-14	20-May-14	21-May-14	22-May-14	23-May-14	24-May-14	25-May-14	26-May-14	27-May-14		
Observe Time				11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM	11:00AM
Chamber A (W/Pest Repeller)	Quantity	Spider	3	3	3	1	2	1	1	0	0	0	0	0	3	4
		Roaches	7	6	5	0	1	0	0	0	0	0	0	0	2	5
	Consumed food(g)	Ants	4	6	4	1	0	0	1	0	0	0	0	0	6	7
		Consumed water(ml)	0.6	1.6	0	0	0	0	0.2	0	0	0	0.2	0.2	0.2	0.6
	Chamber B	Quantity	Spider	7	7	7	9	8	9	9	9	10	10	10	10	7
Roaches			3	4	5	10	9	9	10	10	10	10	10	8	5	5
Consumed food(g)		Ants	6	4	6	9	10	9	10	9	10	10	10	4	3	3
		Consumed water(ml)	0.2	1.0	0.2	0.2	0.4	0.8	0.4	0.6	0.6	0.4	0.6	0.4	0.4	0.2
			1.4	8.0	9.2	4.4	5.2	3.4	4.0	4.4	3.6	3.6	3.6	3.0	3.0	3.0

Note: Found 1 spider, 1 roach & 2 ants dead on 17-May-2014; 1 roach & 2 ants dead on 18-May-2014, 1 roach dead on 19-May-2014. Added new spiders, roaches & ants next day.

***** End of Page *****

Page 5 of 10

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501/E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9698 Fax: (86-20) 3205 7538
Website: www.intertek-etisemko.com GZPERF-BRAND V0 (August 16, 2012)

BHH,LLC 002557



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

TEST RESULT (Continued)

For Roaches fecal pellet & urine spots

STAGE/ SWITCH ON/OFF		DATE	SUBJECT	CHAMBER A (W/ PEST PELLER)	CHAMBER B
PRELIMINARY TESTING	SWITCH OFF	17-May-14	ROACHES	Equal	Equal
		18-May-14	ROACHES	Equal	Equal
DURING TESTING	SWITCH ON	19-May-14	ROACHES	Equal	Equal
		20-May-14	ROACHES	Little	More
		21-May-14	ROACHES	Little	More
		22-May-14	ROACHES	Little	More
		23-May-14	ROACHES	Little	More
		24-May-14	ROACHES	Little	More
		25-May-14	ROACHES	Little	More
POST TESTING	SWITCH OFF	26-May-14	ROACHES	Little	More
		27-May-14	ROACHES	Equal	Equal

Note:

Fecal pellet and urine are observed and witnessed by naked eye. Due to tiny and irregular sizes, Ants, Spiders and Roaches' fecal pellet & urine spots are not easy to count, therefore quantity difference is described by three levels-little, very little and more.


***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

Appendix I




***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

Appendix II




***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

Appendix III



***** End of Page *****



INTELLITEC
INTERNATIONAL
INC.

140515021GZU-002

REVISION SUMMARY

Date	Project Handler Reviewer	Page	Description of Change
2014-7-7			Initial release

*******End of Report*******

Page 10 of 10

Intertek Testing Services Shenzhen Ltd. Guangzhou Branch
Room 02, 1-8/F & Room 01, E101/E501//E601/E701/E801 No.7-2, Guang Dong Software Science Park, Caipin Road, Guangzhou
Science City, GETDD Guangzhou Tel: (86-20) 8213 9688 Fax: (86-20) 3205 7538
Website: www.intertek-etisemko.com GZPERF-BRAND V0 (August 16, 2012)

BHH,LLC 002562

2015 RATS/ MICE TEST REPORT RESULT ANALYSIS

July 7, 2014

Construction of Test Chamber:

- The test was conducted in two plastic chambers. Each chamber was 4' (L) x 4' (W) x 2' (H).
- Ultrasonic Pest Repeller was placed in chamber A. There was no Ultrasonic pest repeller in Chamber B.
- In between, there was an 8.5 feet long plastic tunnel. The tunnel was "curved" and two chambers were designed in Hi-Lo level. The curved and Hi-Lo tunnel design was to further ensure ultrasonic sound wave would not enter from chamber A into chamber B since sound wave was directional.
- All edges were sealed securely with Intertek unbreakable labels. Only Intertek inspector could open the chambers to rats/ mice quantities, weighted food and water and replaced new seals on a daily basis.
- Total 10 rats and 10 mice were used, and tested separately in different chambers.
- Released 50% of rats / mice in chamber A, and another 50% of rats / mice in Chamber B at the beginning of the test.
- There were 3 testing stages:
 - Preliminary Testing: 2 days = 48 hours, pest repeller was OFF
 - During Testing: 7 days = 168 hours, pest repeller was ON
 - Post Testing: 2 days = 48 hours, pest repeller was OFF

Test Result Analysis

Rats (see page 5)

- Preliminary Testing: 40%~60% rates stayed in Chamber A, 60%~40% rates stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 60%~90% rats stayed away from Chamber A, Day 4 ~ Day 7, 100% rates stayed away from Chamber A. Pest repeller was switched ON in Chamber A during testing.
- Post Testing: 30% ~ 60% rates returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand rates' eating behavior under the influence of ultrasonic sound.

Mice – (see page 6)

- Preliminary Testing: 40%~50% Mice stayed in Chamber A, 60%~50% Mice stayed in Chamber B.
- During Testing: Day 1 ~ Day 3, 80% ~ 90% mice stayed away from Chamber A, Day 4 ~ Day 7, 90% ~ 100% mice stayed away from Chamber A. Pest repeller was switched on in Chamber A during testing.
- Post Testing: 40% ~ 60% Mice returned to Chamber A after pest repeller was switched off.
- Water and food consumption was much LESS in Chamber A During Testing when pest repeller was switched on. The consumption quantities were closer in two chambers during Preliminary and Post Testing when pest repeller was switched off. To record water and food consumption result on a daily basis helped to understand ant's eating behavior under the influence of ultrasonic sound.

Fecal Pellets Count (see page 7)

- Lab technician traced and recorded pest fecal pellets on a daily basis, this helped to further understand pest's activities and behaviors under the influence of ultrasonic sound.
- Lab technician could only trace fecal pellets and urine spot was observed:
 - When pest repeller was switched on During Testing; fecal pellets appeared to be much LESS quantities in Chamber A.
 - When pest repeller was switched off during Preliminary and Post Testing, fecal pellet quantities appeared to be more EVEN in two chambers.
- There was neither fecal pellet nor urine spot was found from rats and mice during the entire testing period.